

3 Stage Knife Sharpener Product Code: 00715



Edge Master 3 Stage Knife Sharpener features an ergonomic handle and non-slip rubber base for a safe and secure grip. Incorporating Tungsten Carbide, Diamond and Ceramic stages, this sharpener will take the dullest edged knives back to an edge that will slice through anything. Use the coarse stage for all your metal knives and the medium stage for ceramic and metal knives. The fine stage features a ceramic wheel that will polish and hone the edge back to a razor-sharp finish. Non-slip rubber base. Ideal for recovering dull knives. Not suitable for serrated or scissors.

- 3 Stage pull through sharpener.
- Coarse tungsten carbide construction.
- Medium diamond
- Fine ceramic sharpener.
- Designed with ergonomic handle.

