

3 Stage Ceramic Water Sharpener Product Code: 00716



The Edge Master 3 Stage Water Sharpener is designed to easily and precisely recover your dull cutting edges. Incorporating 3 grades of wheels this sharpener is suitable for all household kitchen knives and will take the dullest knives in your kitchen and make them razor sharp in no time at all. With a non-slip base and ergonomic grip this sharpener is easy to use, safe and suitable for left and right-hand users.

- 3 Stage pull through sharpener.
- Coarse, medium and fine whetstone wheels.
- Ergonomic handle.
- Nonslip rubber base.



